Tools needed to install OceanAir RailShades

Watch how to install video www.zarcor.com

Power driver/drill - with #2 Phillips bit, 2” long

Drill Bits, 1/8, 7/64

Paper & Pencil

Sharpie - red fine point

Isopropyl rubbing alcohol

Windex

Center Punch (spring Loaded)

Tape Measure – Ruler

Paper towels

Phillips screwdriver #2

Spare Phillips screws – 6 gauge x 3/4”

Shop Hammer

Razor knife

Hole filler plugs

Zarcor Inc., 4400 Sunbelt Dr., Addison, TX 75001
www.zarcor.com, 972-380-8724, 800-877-4797